


Z-010WR Tornador Cleaning Gun



Ref.			Ref.		
No.	Part No.	Description	No.	Part No.	Description
1	SPW010001	Housing	17	SPW010017	Inner Tube Assý
2	SPW010002	Nozzle	18	SPW010018	Air Reverse Switch Ass'y
3	SPW010003	Weighted Tube Ass'y	19	SPW010019	Screw
4	SPW010004	Snap Ring	20	SPW010020	Tube Ass'y
5	SPW010005	Pin	21	SPW010021	Cup
6	SPW010006	Trigger	22	SPW010022	Cap with hole
7	SPW010007	Gasket	23	SPW010023	Nut
8	SPW010008	Screw	24	SPW010024	Gasket
9	SPW010009	O-Ring 2x1			
10	SPW010010	Bushing		77-010 1 pcs. SPW010021 Cu	Accessories Cup assembly containing
11	SPW010011	O-Ring			1 pcs. SPW010021 Cup
12	SPW010012	Valve Stem			1 pcs. SPW010024 Gasket
13	SPW010013	Spring			1 pcs. SPW010022A Cap closed
14	SPW010014	Air Inlet (1/4"PF)			
15	SPW010015	Nipple			

Ver.2010-08-1