



19	POT
18	Tube Ass'y
17	Nut
16	Gasket
15	Cap
14	Air Reverse Switch Ass'y
13	Inner Tube Ass'y
12	Air Inlet (1/4"PF)
11	Valve stem
10	Screw
9	Spring
8	E-ring
7	Trigger
6	Pin
5	Housing
4	Screw
3	Rotate set
2	Nozzle (Brush)
1	Nozzle
Part No.	Description